Thermo-optical effects

Oliver Puncken

Outline

- Overview on thermo-optical effects in lasers
 - Thermal lensing
 - Birefringence
 - Depolarization
- Aberrations and the PSL working point
- Attempts for optimization of the PSL laser crystals
 - Different doping concentrations
 - Segmented crystals
 - Intrinsic depolarization compensation


2

Outline


- Overview on thermo-optical effects in lasers
 - Thermal lensing
 - Birefringence
 - Depolarization
- Aberrations and the PSL working point
- Attempts for optimization of the PSL laser crystals
 - Different doping concentrations
 - Segmented crystals
 - Intrinsic depolarization compensation

3

Thermo-optical effects




Thermo-optical effects



- Pump light is partly converted to heat
- Cooling of barrel → temperature gradient
- Thermal lensing in longitudinal pumped laser rods:
 - Time independent heat conduction equation:

$$\nabla^2 T(x,y,z) = -Q(x,y,z) / k,$$

where *Q*: thermal energy, *k*: conductivity




Refractive index change


$$n(r) = n_o \cdot (1 - \gamma r^2),$$

where y=y (pump power, **created heat**, heat conductivity, crystal length, dn/dT, ...)


 → thermal lens with refractive power, which rises linear with the pump power





- Testbeam:
 - 980 nm DFB diode, fundamental mode
 - 650 μm beam radius
 - → thermal refractive power of 0.027 dpt/W.




- Laser stability:
 - Increase pump power in asymmetric resonator until it becomes unstable
 - Thermal lens at this point: $D=1/(I_{long}+L/(2n))$











Thermal refractive power: 0.021 dpt/W


- Wavefront sensor
 - Quite sensitive for fluctuations → big errors
 - Thermal refractive power from Zernike defocus coefficient c₂₀:


$$D = 4 \cdot c_{20} \cdot \lambda / r_0^2$$






Wavefront sensor





Refractive power: about 0.025 dpt/W


Thermo-optical effects



Birefringence and bifocussing


Heating power Different refractive indices for radial and tangential polarization components of the laserlight (birefringence) **Bifocussing**

Effect on the mode radius of an asymmetric two head resonator




Birefringence and bifocussing

Heating power Different refractive indices for radial and tangential polarization components of the laserlight (birefringence) Phase shift for pol. components depends on the radial position → **Depolarization**




Birefringence compensation




Principle:

- Exchange polarization components by 90° rotation between crystal passes
- Imaging of the thermal lens' principal planes results in compensation of phase shifts



Thermo-optical effects



Outline

- Overview on thermo-optical effects in lasers
 - Thermal lensing
 - Birefringence
 - Depolarization
- Aberrations and the PSL working point
- Attempts for optimization of the laser crystals
 - Different doping concentrations
 - Segmented crystals
 - Intrinsic depolarization compensation


17

Aberrations

- Thermal lens as a result of absorption of pump-(and laser-) light
- For homogenious pumplight distribution: radially parabolic temperature profile
- For radially inhomogenious pumplight distribution: radially parabolic temperature profile might be roughly true, but (mainly spherical) aberrations appear

Measurement of aberrations


- Shack Hartmann sensor
 - The lateral position of a (micro-) lens spot depends on the mean slope of the incoming wavefront
 - The mean slope of the wavefront can be calculated from the spotdisplacement




Zernike Polynomials

- The optical path difference of a wavefront W can be developed as a sum of polynomials and their coefficients
- Zernike polynomials are common, because each polynom correspond to a kind of aberration


$$W(\rho,\theta) = \lambda \cdot [c_{00} + \sum_{n=1}^{\infty} \sum_{l=-n}^{n} c_{n} Z_{n}^{l}]$$




Zernike Polynomials





Test setup – Results for LIGO xtal



Experimental investigations










Influence of spherical aberrations on beam profile

 Asymmetric resonator splits the stability range into two parts with respect to the pump power




- Asymmetric resonator splits the stability range into two parts with respect to the pump power
- Spherical aberration are used as control mechanism for TEM₀₀ working point:
 Higher order modes experience a lower effective thermal lens!





- Laser mode radius in first crystal
- Mode radius = stability criterium
- Higher order modes → larger radius
- •Aberrations of the thermal lens → HOM shifted towards higher pump powers
- Values derived by an ABCD calculation of the actual resonator including the thermal lens


 Output beam profile of the free running laser oscillator at an output power of 176 W



Experimental experiences

(2-head resonator)

- Birefringence compensated two head resonator
- 0.1 at.% doped crystals
- 200W pump power per crystal
- Homogenizer, 2mm diameter





Experimental experiences


(2-head resonator)

- 200W pump power per crystal
- Length of the short resonator arm: 130 mm

Length of the long resonator arm:









Experimental experiences

(2-head resonator)



Power scaling (2-head resonator)

- In general:
 More pump power
 → more output
 power
- Adapt resonator to get TEM₀₀-operation
- Limits:
 - pump power
 - mechanics



Outline

- Overview on thermo-optical effects in lasers
 - Thermal lensing
 - Birefringence
 - Depolarization
- Aberrations and the PSL working point
- Attempts for optimization of the laser crystals
 - Different doping concentrations
 - Segmented crystals
 - Intrinsic depolarization compensation

32

Typical accuracy in Nd:YAG doping specified as 0.01 at.%

10% for 0.1 at.% doped crystals


1% for 1 at.% doped crystals

→ The properties of higher doped crystals are more


reliable

 Manufacturing process causes a longitudinal absolute doping gradient


 Higher doped crystals are more common



- Pump wavelength needs to be shifted to get less absorption in order to avoid extreme stresses
 - → which pump wavelength is needed, if everything is supposed to be identical (except the doping)?




- Pump wavelength needs to be shifted to get less absorption in order to avoid extreme stresses
 - → which pump wavelength is needed, if everything is supposed to be identical (except the doping)?




Note: this calculation is based on a constant heat fraction!

Comparison with standard crystal – in identical setups




0.13 at.%, 808 nm




0.68 at.%, 802 nm

Comparison with standard crystal – in adapted setups




0.13 at.%, 808 nm




0.68 at.%, 802 nm

ICTS Winter School 2013

Comparison with standard crystal – in adapted setups




0.13 at.%, 808 nm



0.48 at.%, 802 nm


- Learned from these Experiments:
 - Thermal refractive power can be estimated from the resonator length
 - The fraction of pump light, converted into heat can be estimated from the refractive power




ICTS Winter School 2013


- Learned from these Experiments:
 - Thermal refractive power can be estimated from the resonator length
 - The fraction of pump light, converted into heat can be estimated from the refractive power
 - The fraction of fluorescense, stimulated emission, and inactive Nd ions ("dead sites") can be estimated

Here: 22% of the ions are assumed to be optically inactive



Highly doped crystals: non-constant heat coefficient





Outline

- Overview on thermo-optical effects in lasers
 - Thermal lensing
 - Birefringence
 - Depolarization
- Aberrations and the PSL working point
- Attempts for optimization of the laser crystals
 - Different doping concentrations
 - Segmented crystals
 - Intrinsic depolarization compensation


Segmented crystals

 The maximal pump power (and therefore output power) is limited by the induced heat and occurring stresses

 Longitudinally homogeneous temperature distribution

 Optimum: longitudinal hyperbolic doping gradient* (Figure: 807 nm, FWHM 2.5 nm, 95% absorption)


complex manufacturing process




Segmented crystals

- © Tradeoff: segmented crystals
 - Pump wavelength: 807.8 nm
 - Doped length: 40 mm
 - 3 doped segments

Segment	Length	Doping
1	7 mm	0 at.%
2	22 mm	0.1 at.%
3	11 mm	0.23 at.%
4	7 mm	0.6 at.%
5	7 mm	0 at.%




Optimal pump wavelength



Segmented crystals

Comparison with "standard crystal"




- No difference in laser performance
- No pump light double-pass
- Complex in manufacturing

Outline

- Overview on thermo-optical effects in lasers
 - Thermal lensing
 - Birefringence
 - Depolarization
- Aberrations and the PSL working point
- Attempts for optimization of the laser crystals
 - Different doping concentrations
 - Segmented crystals
 - Intrinsic depolarization compensation

Standard birefringence compensation



- + very effective (depolarization losses < 1 %)
- Additional components inside the resonator (absorption, thermal effects, spots,...)
- Alignment sensitivity


Intrinsic birefringence reduction

Pumped crystal becomes birefringent

→ Depolarisation D $D(x,y)=\sin^2(2(\theta(x, y)-y))\sin^2(\psi(x,y)/2)$


• Angle between input polarization and principal axis of the birefringence ellipsoid

y Angle between input polarization and x-axis of the reference system




Intrinsic birefringence reduction


For [100]- and [110]-cut crystals:
 The depolarization depends on the orientation of the crystal with respect to the polarization orientation of the laser



- Wavelength: 1053 nm
 - No amplification in pumped Nd:YAG crystal
 - Close to Nd:YAG laser wavelength




• [111]-cut: beam pattern rotates



[111]-cut: beam pattern rotates


 [100]-cut: beam pattern changes with respect to input polarization
 Principal axis of the refractive index ellipsoid are no longer radially/tangentially oriented




• [111]-cut: beam pattern rotates

 [100]-cut: beam pattern changes with respect to input polarization
 Principal axis of the refractive index ellipsoid are no longer radially/tangentially oriented


• [110]-cut: Elliptical pattern at 45° with maximum at the center



Investigations with asymmetric two-head laser



Investigations with asymmetric two-head laser



Acknowledgment

Data and pictures taken from:

(former) LZH researchers: Oliver Puncken, Marcin Damjanic, Maik Frede, Raphael Kluzik, Dietmar Kracht, Bastian Schulz, Christian Veltkamp, Peter Weßels, Ralf Wilhelm, Lutz Winkelmann et al.

(former) AEI researchers: Christina Bogan, Patrick Kwee, Jan Pöld, Frank Seifert, Benno Willke et al.

LIGO Document Control Center (DCC)

Thanks!